

STOP! READ FIRST!!

Fixture must have silicone plugs installed in proper orientation




Downlight

Luminaires MUST have silicone plugs installed in all locations (6 per 4 ft)



Uplignt Luminaires DO NOT USE



Angled Uplight

Luminaires over 30 Degrees MUST HAVE upper hole and middle hole PLUGGED! Leave lower right hole un-plugged.

STOP: READ FIRST::